

STOCK MOULDINGS



Morgan-Wightman Supply Company


Wholesale Building Materials Since 1950

www.morgan-wightman.com


5668 Anglum Court
Hazelwood, MO 63042
Phone: (314) 895-1111
Fax: (314) 895-3201

MOULDINGS


PRIMED PINE MOULDINGS



CROWN
P249L
9/16" X 3-5/8" X 16'



CROWN
P247
9/16" X 4-5/8" X 16'




CROWN
P251M
11/16" X 5-1/4" X 18'




COLONIAL CASING
P2366
11/16" X 2-1/4" X 14'

P236684
11/16" X 2-1/4" X 7'



COLONIAL CASING
P2366L
11/16" X 3-1/4" X 16'

P2366L86
11/16" X 3-1/4" X 7'2"



COLONIAL CASING
P2444M
5/8" X 3-1/4" X 16'

MORGAN-WIGHTMAN SUPPLY COMPANY

PRIMED PINE MOULDINGS



COLONIAL BASE
P2620
9/16" X 4-1/4" X 16'



COLONIAL BASE
P2623
9/16" X 3-1/4" X 16'



COLONIAL BASE
P2633
7/16" X 3-1/4" X 16'



BASE SHOE
P2126
1/2" X 3/4"
6' thru 16'



DECO MOULD
P2C158
11/16" X 1-1/2" X 16'



S4S STOCK
P211163
1-1/16" X 3" X 16'



COLONIAL BASE
P2633L2
7/16" x 2-1/4" x 16'



DOOR STOP
P287684
7/16" X 1-3/8" X 7'0"
P2876102
7/16" X 1-3/8" X 8'6"




BRICK MOULD
P2180
1-1/4" X 2" X 17'



CHAIR RAIL
P2390L
11/16" X 2-5/8" X 16'

MOULDINGS

EMBOSSED GOLDEN OAK MOULDINGS




PREFINISHED CASING
L33561
7/16" X 2-1/4" X 14'

L3356841
7/16" X 2-1/4" X 7'



PREFINISHED BASE
L36361
3/8" X 2-3/4"
6' thru 14'

RED OAK MOULDINGS



COLONIAL BASE
O623
9/16" X 3-1/4" - R/L




COVE MOULD
O8095
3/4" X 3/4" - RL



BASE SHOE
O127
7/16" X 3/4" - R/L

MORGAN-WIGHTMAN SUPPLY COMPANY

MDF MOULDINGS



ULTRA-LIGHT CROWN
ULCR514
5-1/4" X 16'



COLONIAL BASE
MDF218
9/16" X 5-1/4" X 16'
(shown)


MDF217414
9/16" X 4-1/4" X 16'



FLUTED CASING
MDF715
11/16" X 5-1/4" X 16'



OGEE STOOL
MDFOG5
11/16" X 5-1/2" X 16'




COLONIAL CASING
MDF366
5/8" X 2-1/4" X 16'




COLONIAL BASE
MDF623
12mm x 3-1/4" x 16'0"

MOULDINGS


SOLID PINE MOULDINGS




CROWN
P149L
9/16" X 3-5/8"
10' thru 16'




CROWN
P148L
11/16" X 4-1/4"
10' thru 16'




CROWN
P147L
11/16" X 5-1/4"
10' thru 16'



BED
P174
9/16" X 1-3/4"
8' thru 16'




RANCH CASING
P1327
11/16" X 2-1/4"
8' thru 16'



COLONIAL CASING
P1366
11/16" X 2-1/4"
8' thru 16'


P136684
11/16" x 2-1/4" x 7'



COLONIAL CASING
P1366L
11/16" X 3-1/4"
10' thru 16'

P1366I86
11/16" X 3-1/4" X 7'2"

SOLID PINE MOULDINGS



HANDRAIL
F1231
1-1/2" X 1-11/16"
14' AND 16'



BASE SHOE
P1126
1/2" X 3/4"
6' thru 16'



QUARTER ROUND
P1106
3/4" X 3/4"
8' thru 16'



QUARTER ROUND
P1110
1/4" X 1/4" x 8'



CAP MOULD
P194R
1-1/16" X 1-5/8"
8' thru 16'



SCREEN MOULD
P1142
1/4" X 3/4"
8' thru 16'



COVE MOULD
P193
3/4" X 3/4"
6' thru 16'



MULL CASING
P1268
1/4" X 1-1/8" X 7'

MULL CASING
P1265
1/4" X 1-3/4"
7' thru 14'




PANEL MOULD
P170PM
1/2" X 1-1/4"
8' thru 16'



OUTSIDE CORNER
P1206
3/4" X 3/4"
8' thru 16'



DOOR STOP
P1876
7/16" X 1-3/8"
8' thru 16'



DOOR STOP
P193684
7/16" X 1-3/8" X 7'
P193696
7/16" X 1-3/8" X 8'




PARTING STOP
P1254
1/2" X 3/4"
8' thru 16'



CHAIR RAIL
P1390
11/16" X 2-5/8"
8' thru 16'




S4S STOCK
P121323
21/32" X 3"
10' thru 16'



S4S SQUARE STOP
P1239
3/4" X 3/4"
8' thru 16'


SOLID PINE MOULDINGS



COLONIAL BASE
P15180
9/16" X 5-1/4"
10' thru 16'




COLONIAL BASE
P1620
9/16" X 4-1/4"
10' thru 16'




COLONIAL BASE
P1623
9/16" X 3-1/4"
10' thru 16'



COLONIAL BASE
P1633L
7/16" X 2-1/4"
10' thru 16'



T-ASTRAGAL
For 1-3/8" Doors
Routed For
Recessed Flush Bolt
TAST980L
TAST980R



BRICK MOULD
P180
1-1/4" X 2"
8' thru 16'



DECO MOULD
P1B118
1/2" X 1"
12' thru 16'



DECO MOULD
P1C158
11/16" X 1-1/2"
10' thru 16'

MORGAN-WIGHTMAN SUPPLY COMPANY

CUSTOM MOULDINGS



**BUTTERFLY/FLUTED
SOLID PINE CASING**
21/32" X 3-1/2"
P1BF36808 — 8'
P1BF36816 — 16'

**BUTTERFLY/FLUTED
PRIMED PINE CASING**
21/32" X 3-1/2"
P2BF36808 — 8'
P2BF36816 — 16'




SOLID PINE BUTTERFLY CASING
21/32" X 5-1/4"
P1BF66808 — 8'
P1BF66816 — 16'

PRIMED PINE BUTTERFLY CASING
21/32" X 5-1/4"
P2BF66808 — 8'



SOLID PINE FLUTED CASING
21/32" X 5-1/4"
P1FL66816 — 16'



SOLID PINE CHAIR RAIL
MWPCR1
3/4" X 3-3/8" X 17'


FINGER JOINT POPLAR CHAIR RAIL
MWPCR1FJ
3/4" X 3-3/8" X 16'



SOLID PINE PANEL MOULD
MWPPM1
3/4" X 2-1/4" X 16'

FINGER JOINT POPLAR PANEL MOULD
MWPPM1FJ
3/4" X 2-1/4" X 16'

ROSETTE & PLINTH BLOCKS





WELLINGTON ROSETTE WITH OASIS EDGE

ROSETTE
RB212
1-1/16" X 2-1/2"

ROSETTE
RB334
1-1/16" X 3-3/4"

ROSETTE
RB512
1-1/16" X 5-1/2"



FEDERAL PLINTH BLOCK

PLINTH BLOCK
PB334
3-3/4" X 8"

PLINTH BLOCK
PB512
5-1/2" X 8"

DENTIL MOULD



SOLID PINE
P18300
9/16" X 1-11/16"
Dist. Of Teeth
3/4"

SOLID PINE
P18343
3/4" x 3"
Dist. Of Teeth
1-1/4"

PRIMED PINE
P28300
1-1/16" X 3"
Dist. Of Teeth
1-5/8"

SOLID POPLAR
P18600
1" X 5-1/2"
Dist. Of Teeth
1-5/8"

HOW TO "BUILD-UP" WOOD MOULDINGS TO CREATE LARGER PROFILES

Get the "Colonial" Look or a New "Contemporary" Look By Combining Various Standard Wood Moulding Patterns.


WHERE TO USE 'BUILT-UP' MOULDINGS

CEILING



The most obvious area for "built-up" mouldings is where the walls meet the ceiling. This is primarily true of rooms with high ceilings. However, in low ceiling rooms (8 ft.), single moulding profiles usually work best. A series of "built-up" mouldings would have a tendency to make a low ceiling appear even lower. But if your ceilings are high (10 ft. or higher), there is no limit to the

rich 3-dimensional elegance you can add to the room's appearance with the creative application of "built-up" mouldings. Following are several suggested combinations, but don't be limited to these. Let your imagination create your own combinations and designs.

CHAIR RAILS



Adding chair rails to a room is a very traditional method of breaking up walls, adding both interest and protection. It prevents the wall from being bumped or scuffed by chairs and can also be used to separate two types of decorating material such as paneling, wallpaper and paint. Following are some variations of "built-up" chair rail profiles.




Drawings Courtesy of the "Wood Moulding & Millwork Producers Assn."

MORGAN-WIGHTMAN SUPPLY COMPANY

MOULDINGS



FIREPLACES

The use of "built-up" mouldings is also an excellent way to highlight or frame your fireplace or add depth and richness to the fireplace mantel.




DOORS AND WINDOWS

The framing of doors and windows is most commonly done with single moulding profiles, but by adding other patterns, the basic trim can be easily transformed into a window or door casing of classical depth and beauty.



BASE

The elaborate look of elegance can even be carried through to base mouldings where the wall meets the floor, as illustrated in the following variations.



Drawings Courtesy of the "Wood Moulding & Millwork Producers Assn."

MORGAN-WIGHTMAN SUPPLY COMPANY